


Technical Information



The Beckhoff terminals are implemented in the firmware according to a given order

1. E65 19020 - Analog Input / EL 3104
2. E65 19040 - Digital Input / EL 1018
3. E65 19030 - Analog Output / EL 4034
4. E65 19050 - Digital Output / EL 2008

It is possible to install a max value of this Beckhoff Terminals up to:

1. E65 19020 - Analog Input / EL 3104 → 4 pieces / 16 Signals
2. E65 19040 - Digital Input / EL 1018 → 6 pieces / 48 Signals
3. E65 19030 - Analog Output / EL 4034 → 2 pieces / 8 Signals
4. E65 19050 - Digital Output / EL 2008 → 6 pieces / 48 Signals

Otherwise , an additional bus coupler can be added

Settings	
Number of evaluated signals (analog inputs)	16
Number of evaluated signals (digital inputs)	48
Number of evaluated signals (analog outputs)	8
Number of evaluated signals (digital outputs)	48

Picture 1 _ Driver "Ethercat Remote IO"